

TECHNICAL DATA

CV Series ClirVu® Infrared Windows



**QUARTER TURN LATCH EASILY OPENS
HINGED COVER**

**CORROSION AND UV RESISTANCE
FOR CHALLENGING OUTDOOR
ENVIRONMENTS**

**THREE SIZES: 50 MM, 75 MM, AND 95 MM
(2 INCH, 3 INCH, AND 4 INCH) WITH
THE OPTION OF HAND TURN OR
SECURITY KEY DOOR LATCHES**

Compliance without compromise. Safety without sacrifice.

Increase the safety and speed of electrical thermal imaging inspections with the new Fluke ClirVu® IR Windows. Reduce the risk of arc-flash and electrocution, increase the safety of your personnel and reduce the time and cost of preventive maintenance.

- No more removing the panel door for installation
- Work permit requirements and NFPA 70E processes are significantly reduced
- Full PPE is often not required so inspections are done faster and more comfortable

Superior arc blast protection

- High temperature silicon gaskets
- Mounting and door latches provide high pressure gasket compression
- Die cast components are manufactured with the highest strength alloys
- Jam nut screws are made from 4037 steel, heat treated to 160,000 psi tensile

Torture Tested to the highest test ratings

- IEEE C37.20.7 63 kA Arc tested at KEMA, UL 50/50E/50V, UL1558, IEC60529-1: IP67, IEC 60068, NEMA 4/12, CSA C22.2 NO. 14-13:2012, and CE

Quick and easy installation

- Installation takes 5 minutes with one technician
- Only one hole necessary with standard Greenlee® punch. Rear access required for punch connection only (Easily accomplished with one technician)
- Installs from front; no template needed; no rear access required
- Grounds instantly to metal enclosure with patent pending AutoGround™ process
- Sharp teeth on jam nuts assure four gas-tight ground connections
- All components have electrically conductive finishes for optimum grounding

Specifications

Key Features	CV400	CV401	CV300	CV301	CV200	CV201
Size	95 mm (4 in)		75 mm (3 in)		50 mm (2 in)	
Voltage range	Any					
NEMA environment type	Type 4/12 (indoor/outdoor)					
AutoGround™	Yes					
ClirVu® optic	Yes					
Operating temperature	-40 °C to +232 °C (-40 °F to +450 °F) and +260 °C (500 °F) Intermittent					
Compatible with all Fluke cameras	Yes					
Jam nut locking system	Yes					
Cover and fastener permanently attached	Yes					
Single-hole install	Yes					
Hand turn and security key door latch options	Yes					
Visual inspection and fusion capable	Yes					
Short/Mid/Long-wave IR and UV capable	Yes					
Ratings and testing						
Arc-tested (IEEE C37.20.7)	63 kA for 30 cycles @ 60 Hz at KEMA					
UL 50V component recognition	Yes					
UL 50 /NEMA environmental rating	NEMA Type 4/12					
UL1558	Yes					
CSA C22.2 No.	Yes					
CSA type rating	Type 4					
IP rating	IP67 at TUV					
Lloyds register	Up to 11 kV marine switchgear, indoor or outdoor (offshore only)					
Vibration rating	IEC60068-2-6 at TUV					
Humidity rating	IEC60068-2-3 at TUV					
Install						
Actual mounting hole diameter required	115.42 mm (4.544 in)		89.89 mm (3.539 in)		61.37 mm (2.416 in)	
Greenlee® punch kit = punch/die	K3BB-4 = K3P-4/2983AV		K3BB-3 = 1431AV/1432 AV		K3BB-2 = K3P-2/442AV	
Recommended max panel thickness	10 gage					
Overall window height	189.3 mm (7.45 in)		141.5 mm (5.57 in)		112.9 mm (4.45 in)	
Overall window width	147.1 mm (5.79 in)		111.5 mm (4.39 in)		83.0 mm (3.27 in)	
Overall window thickness	23.0 mm (0.90 in)		16.2 mm (0.64 in)		16.2 mm (0.64 in)	
Door latch	Hand Turn	Security Key	Hand Turn	Security Key	Hand Turn	Security Key
Optics						
Optic insert diameter	95 mm (3.74 in)		75 mm (2.96 in)		50 mm (1.97 in)	
Viewing aperture diameter	87.63 mm (3.450 in)		67.95 mm (2.675 in)		42.93 mm (1.690 in)	
Viewing aperture area	6032 sq.mm (9.35 sq.in)		3626 sq.mm (5.62 sq. in)		1445 sq.mm (2.24 sq. in)	
Thickness	4 mm (0.16 in)		2 mm (0.08 in)			
Other						
Warranty	Lifetime replacement against manufacturing defects					





Ordering information

CV200 2 in (50 mm) IR Window, Hand Turn Door Latch

CV201 2 in (50 mm) IR Window, Security Key Door Latch

CV300 3 in (75 mm) IR Window, Hand Turn Door Latch

CV301 3 in (75 mm) IR Window, Security Key Door Latch

CV400 4 in (95 mm) IR Window, Hand Turn Door Latch

CV401 4 in (95 mm) IR Window, Security Key Door Latch

Included

Fluke IR Windows are supplied complete, assembled and ready for installation. In addition to the IR Window each carton contains warranty statement and security key if that option is ordered.

Visit [fluke.com/irwindows](https://www.fluke.com/irwindows) to get complete details on these products or ask your local Fluke sales representative.

Fluke. Keeping your world up and running.™

©2024 Fluke Corporation.
Specifications subject to change without notice.
240507-en

Modification of this document is not permitted without
written permission from Fluke Corporation.