

1AC II Volt Alert LVD1/LVD2 Volt Lights SM100/200/300 SocketMaster Testers

FLUKE®



Fluke 1AC II

Fluke 1AC II VoltAlert™

The Fluke VoltAlert AC voltage detector is very easy to use – just touch the tip to a terminal strip, outlet or cord. When the tip glows red and the unit beeps, you know there is voltage on the line.

- It continually tests its battery and its circuit integrity with a periodic double flash visual indication.
- Highest safety rating: CAT IV 1000V
- Detects voltage without metallic contact

Operating range: 200 – 1000V AC
Batteries: Two AAA Alkaline
Size (H): 148 mm
Two Year Warranty



LVD1

LVD1 Volt Light

Dual sensitivity voltage detector

- Detects voltage from 40V to 300V AC
- Blue light means you're close
- Red light means you're at the source
- Comes with a versatile clip to secure light to pocket, hat or even panel door



LVD2

LVD2 Volt Light

Combines bright light and voltage detection in one pen style design

- Dual sensitivity
- Detects voltage from 90V to 600V AC
- Blue light means you're close
- Red light means you're at the source
- Rated to CAT IV 600V

SM100/200/300 SocketMaster Testers

The fast way to check if your sockets are safe.



SM100



SM200



SM300

Only available with UK plug

Ordering Information

Fluke 1AC II	VoltAlert
Fluke 1AC II 5PK	VoltAlert (5-pack)
LVD1	Volt Light
LVD2	Volt Light
SM100	SocketMaster Tester
SM200	SocketMaster Tester
SM300	SocketMaster Tester

Features

	SM100	SM200	SM300
Clear indication of wiring status	•	•	•
Audible notification of wiring status		•	•
Unique soft-touch RCD test checks 30 mA RCD's for trip within 300 ms			•
Earth Volts Touchpad detects raised earth voltages >50 V, indicating potentially dangerous situations			•